Direct Programming

Find the brand of your set in part two of this booklet.

Press the key corresponding to the device you want (TV, DVD VCR, SAT DTT, AUX for **Universal4**), (TV or DVD SAT/DTT VCR for **Universal2**); the LED gives a short blink.

Keep keys ⏻ and MUTE pressed down until the LED stays lit; release the keys. **FIG.3.**

Enter the four digits found; the LED confirms by giving two blinks. **FIG.4.**

Check that the device is working properly; if all the functions are not present try the next code.

If Direct Programming is not successful:

S.O.S.

Automatic Programming

Switch on your set. (PLAY for DVD/VCR).

Press the key corresponding to the device you want (TV, DVD VCR, SAT DTT, AUX for **Universal4**), (TV or DVD SAT/DTT VCR for **Universal 2**); the LED gives a short blink.

Keep keys ⏻ and MUTE pressed down until the LED stays lit; release the keys. **FIG.3.**

Press key 0 and then the type of device you want (1 for TV, 2 for DVD/VCR, 3 for HI-FI, 4 for SAT); the LED blinks about every 3 seconds. **FIG.5**

As soon as the device goes off, press any key on the keypad; the LED confirms by blinking twice.

Check that the device is working properly; if all the functions are not present repeat **Automatic Programming.**

Displaying the Active Code

Press the key corresponding to the device you want (TV, DVD VCR, SAT DTT, AUX for **Universal4**), (TV or DVD SAT/DTT VCR for **Universal2**); the LED gives a short blink.

Keep keys ⏻ and MUTE pressed down until the LED stays lit; release the keys. **FIG.3.**

Press key 9 **(FIG.6);** the LED starts to blink displaying the active code, as in the example:

if the active code is 1203 the LED first gives 1 blink, to indicate 1; then, after about one second, 2 blinks, to indicate 2; then 1 long blink, to indicate 0; and finally 3 blinks, to indicate 3.